

Gebrauchsanweisung emoskop

Fernrohr + Lupe = Mikroskop

Kombination als Fernrohr 2,5x • Lupe 5x, 10x und 15x • Mikroskop 25x – 30x

Nun haben Sie das kleine optische Universalgerät **emoskop**, das Fernrohr, Lupe und Mikroskop in sich vereinigt, in Händen.

Fernrohr: Wenn Sie die vordere Linse (C) abschrauben, ergibt die Kombination der beiden anderen Teile (A und B) ein Fernrohr mit Theaterglassvergrößerung (2,5x). Um das Gerät nun auf Ihr Auge einzustellen, bewegen Sie Teil A in schiebender bzw. ziehender Weise gegen Teil B.

Lupe 5x: Eine 5fach vergrößernde Lupe erhalten Sie, wenn Sie Teil B alleine benutzen, und zwar halten Sie die Lupe in der Weise, daß das Rohr Ihrem Auge zugewandt ist, da sonst der Bildausschnitt kleiner wird.

Lupe 10x: Teil C für sich ist eine 10fach vergrößernde Lupe.

Lupe 15x: Die Kombination der Teile B u. C (C wird auf B aufgeschraubt) ergibt eine Lupe von 15facher Vergrößerung. Sie halten diese Lupe wieder in der Weise, wie unter „Lupe 5x“ geschildert.

Mikroskop: Benutzen Sie alle Teile (A, B und C), also Fernrohr und aufgeschraubte 10fache Lupe, mit eingeschobenem Teil A, so erhalten Sie ein Mikroskop von 25facher Vergrößerung. Ziehen Sie nun das Okular (Teil A) aus dem Objektivtubus (Teil B), so stehen Ihnen die Vergrößerungen von 25fach bis 30fach zur Verfügung.

Wir hoffen, das kleine **emoskop** wird immer Ihr Begleiter sein und Ihnen stets gute Dienste erweisen. Sicher wird es Ihnen viel Freude bereiten.

Wenn Sie weitere Wünsche haben sollten, wenden Sie sich bitte an uns. Wir stehen Ihnen mit unserem reichhaltigen Fabrikationsprogramm gerne zur Verfügung.

EMO-OPTIK Arthur Selbert WETZLAR



Instructions for the emoskop the combined telescope, magnifier and microscope

The **emoskop** is a telescope with a power of 2.5x; used as a magnifier it gives magnifications of 5x, 10x and 15x; as a microscope 25x - 30x.

You are now the owner of the little optical universal instrument called **emoskop**, the combination of telescope, magnifier and microscope.

Telescope: Unscrew and remove front lens C; the combination of the two other parts A and B is now a theatre glass with a magnification 2.5x. The instrument can be adjusted to your own eyesight by sliding part A over part B.

Magnifier 5x: Part B by itself constitutes a magnifying glass with a power of 5x; it is used with the tube end nearest to the eye, as otherwise the field of view would be smaller.

Magnifier 10x: Part C by itself gives a magnification of 10x.

Magnifier 15x: Parts B and C combine to form a magnifying glass of the high magnification of 15x. The tube part is once more nearest to the eye.

Microscope: All three parts A, B, and C together (telescope plus screwed-on 10x magnifier) become a microscope with a power of 25x. By pulling the ocular (part A) out of the objective tube (part B), magnifications between 25x and 30x can be obtained.

We trust that our little **emoskop** will become your constant companion and will render much excellent service. It will certainly give you a great deal of pleasure!

Should you have any further wishes, kindly write to us; our comprehensive list of products is waiting to be sent to you.

EMO-OPTIK Arthur Seibert WETZLAR Germany



A



B



C